



Fig. 66. Circuit diagram, 4-cylinder 'Regular', 'Long' and Station Wagon Petrol models, negative earth

**Key to circuit diagram, 4-cylinder 'Regular', 'Long' and Station Wagon Petrol models, negative earth**

- |    |  |    |  |
|----|--|----|--|
| 1  | Starter motor  | 29 | Switch, stop lamp  |
| 2  | Solenoid, starter motor                              | 30 | Switch, wiper  |
| 3  | Horn push button                                     | 31 | Indicator unit, flashers   |
| 4  | Horn   | 32 | Switch and warning light for flashers  |
| 5  | Panel light, speedometer                             | 33 | Dynamo   |
| 6  | Switch, panel light                                  | 34 | Warning light, ignition  |
| 7  | Panel light, instruments                             | 35 | Warning light, oil pressure  |
| 8  | Side lamp, RH  | 36 | Switch, cold start on control  |
| 9  | Side lamp, LH  | 37 | Fuel gauge   |
| 10 | Tail lamp, RH  | 38 | Temperature gauge  |
| 11 | Tail lamp, LH  | 39 | Wiper motor  |
| 12 | Headlamp, RH, dipped beam                            | 40 | Switch, oil pressure   |
| 13 | Headlamp, LH, dipped beam                            | 41 | Distributor  |
| 14 | Headlamp, LH, main beam                              | 42 | Switch, cold start in cylinder head  |
| 15 | Headlamp, RH, main beam                              | 43 | Fuel tank unit   |
| 16 | Warning light, headlamp main beam                    | 44 | Temperature transmitter unit   |
| 17 | Battery, 12 volt                                     | 45 | Stop lamp, RH  |
| 18 | Switch, ignition and starter                         | 46 | Stop lamp, LH  |
| 19 | Switch, lights                                       | 47 | Socket, wiper lead   |
| 20 | Switch, headlamp dip                                 | 48 | Front flasher, RH  |
| 21 | Inspection sockets                                   | 49 | Rear flasher, RH   |
| 22 | Fuse, A1-A2 (35 amp)                                 | 50 | Rear flasher, LH   |
| 23 | Fuse, A3-A4 (35 amp)                                 | 51 | Front flasher, LH  |
| 24 | Feed, interior light                                 |    |  |
| 25 | Regulator box  |    | Snap and Lucar connections —  — |
| 26 | Ignition coil  |    |  |
| 27 | Warning light, choke                                 |    | Earth connections —  —          |
| 28 | Voltage stabiliser, fuel gauge and temperature gauge |    |  |

**Cable colour code**

B—Black

P—Purple

W—White

R—Red

N—Brown

Y—Yellow

U—Blue

G—Green

L—Light